



CORPORATE
CHAIR
SYSTEMS

HOW TO USE THE STORM CHAIR

**WELCOME TO THE STORM EXPERIENCE, HERE'S
HOW TO SIMPLY ADJUST YOUR NEW STORM CHAIR!**



1. The lever on the right hand side adjusts seat height.



2. Extend the same lever out to unlock recline function. Lean back and lock into place by pushing the lever back into the original position.

To return to the upright or unlock position, extend the lever and gently push back on the backrest to release.




CORPORATE
CHAIR
SYSTEMS

HOW TO USE THE STORM CHAIR



3. To adjust the lumbar support, reach around and lift or lower the handles, depending on where the support is needed.



4. Height adjustable armrest:

Press the button on the outside of the armrest, and then release to set in desired position.



CORPORATE
CHAIR
SYSTEMS

HOW TO USE THE STORM CHAIR



5. Tension control:

Depending on the person's size, the tension will need to be adjusted for the recline. Clockwise will tighten the tension and anti clockwise will make the recline easier.

DESIGNED TO CORRECTLY SUPPORT MANY SHAPES AND SIZES IN A LARGE WORKFORCE, HOPE THIS HELPS YOU EXPERIENCE THE STORM CHAIR BETTER!